



www.regulus.eu



CTC EcoPart 600M

Installation and Maintenance Manual
CTC EcoPart 600M
Model 612M / 616M

EN

CTC EcoPart 600M

Table of contents

1. Important to remember!	5	5.3 Refrigerant pump (G20)	20
1.1 Transportation	5	6. Electrical installation	21
1.2 Positioning	5	6.1 Electric installation 400 V 3N~	21
1.3 Recycling	5	6.1.1 Omnipolar safety switch	21
1.4 After commissioning	6	6.1.2 Alarm output	21
Safety instructions	6	7. Communication connection	22
Checklist	7	7.1 Option 1 - Connection of one heat pump	22
2. Connection alternative CTC EcoPart 600M	8	7.2 Option 2 – Series connection of heat pumps	23
2.1 General	8	7.3 Wiring diagram	26
3. Technical data	9	7.3.1 Cooling module (A3)	26
3.1 Table CTC EcoPart 612M	9	7.3.2 Cooling module (A4)	28
3.2 Table CTC EcoPart 616M	10	7.3.3 Connection box	29
3.3 Výkonové parametry	10	7.4 Parts list	30
3.4 Cooling module component location	12	7.5 Resistances for sensors	31
3.5 Dimensions diagram	13	8. First start	32
3.6 Refrigerant system	14	9. Operation and Maintenance	32
3.7 Delivery includes:	14	9.1 Periodic maintenance	32
4. Installation	15	9.2 Operation stop	32
4.1 Connection of the heat medium side	15	10. Troubleshooting/Appropriate measures	33
4.1.1 Circulation Pumps (Charging pumps) (G11)	15	10.1 Air problems	33
4.1.2 Pump diagram EcoPart 600M	15	10.2 Alarm	33
5. Connecting the ground circuit (brine system)	17	Removing the cooling module	34
5.1 Connections	17		
5.2 Brine system schematic diagram	18		
5.2.1 Valves	18		
5.2.2 Insulation against condensation	18		
5.2.3 Filling and venting	18		
5.2.4 Pressure/level switch	19		
5.2.5 Post-installation check on brine system	19		
5.2.6 Level vessel/Expansion vessel (CTC EcoPart 612M)	19		
5.2.7 Filling kit with dirt filter	19		
5.2.8 Brine	20		
5.2.9 Air pockets	20		
5.2.10 Checking brine difference	20		

Congratulations on buying your new product!



The complete heat pump for rock, ground or lake

The CTC EcoPart 600M is a modulating heat pump which takes heat from bedrock, ground or watercourses, and delivers it to the house's existing heating system.

Tepelné čerpadlo CTC EcoPart je možné připojit k vnitřním jednotkám RegulusBOX, RegulusHBOX, RegulusHBOX K nebo ke stávajícímu otopnému okruhu pomocí CSE IR14.

CTC EcoPart 600M has been designed to operate with high efficiency and low noise levels.

Save this manual containing the installation and maintenance instructions. If it is looked after properly, you will be able to enjoy the use of your CTC EcoPart 600M for many years. This manual will provide all the information you will need.

CTC EcoPart 600M is available in two versions:
CTC EcoPart 612M and CTC EcoPart 616M.

1. Important to remember!

Check the following points in particular at the time of delivery and installation:

1.1 Transportation

- Transport the heat pump to the installation location before removing the packaging. Move the product using one of the following means:
 - Forklift
 - Lifting band around the pallet. NB: Can only be used with the packaging on.
- The heat pump must be transported and stored upright.

1.2 Positioning

- The heat pump must be transported and stored upright.
- Remove the packaging and check before installation that the product has not been damaged in transit. Report any transport damage to the carrier.
- Place the product on a solid foundation, preferably concrete.
If the heat pump needs to be placed on a soft carpet, base plates must be placed under the adjustable feet.
- Remember to leave an access and service area of at least 1 metre in front of the heat pump.
- The heat pump must not be placed below floor level.
- Avoid placing the heat pump in rooms where the walls are of lightweight design, as people

in the adjoining room may be disturbed by the compressor and vibrations.

1.3 Recycling

- The packaging must be deposited at a recycling station or with the installation engineer for correct waste management.
- Obsolete products must be disposed of correctly and transported to a waste station or distributor/retailer offering this service.
Disposal of the product as household waste is not permitted.
- It is very important that the product's refrigerant, compressor oil and electric/electronic components are disposed of correctly.

1.4 After commissioning

- The installation engineer advises the property owner on the design and servicing of the system.
- The installation engineer fills in a checklist and contact information – the customer and installation engineer sign the list, which the customer keeps.
- Make sure that registration for warranty and insurance is made on the CTC's web site:
<https://www.ctc-heating.com/customer-service#warranty-registration>

When contacting CTC, always mention the following:

- Serial number
- Model/Size
- the fault message shown in the display
- Your telephone number



Information in this type of box [i] is intended to help ensure that the product functions optimally.



Information in this type of box [!] is particularly important for correctly installing and using the product.

For your own reference

Fill in the information below. It may come in useful if anything should happen.

Product:	Serial number:
Installer:	Name:
Date:	Tel. no.:
Electrical installer:	Name:
Date:	Tel. no.:

No liability is accepted for any misprints. We reserve the right to make design changes.

Safety instructions



Turn off the power with an omnipolar switch before doing any work on the product.



The product must be connected to protective earth.



The product is classified as IPX1. The product must not be rinsed with water.



When handling the product with a hoist ring or similar device, make sure that the lifting equipment, eyebolts and other parts are not damaged. Never stand under the hoisted product.



Never jeopardise safety by removing bolted covers, hoods or similar.



Any work on the product's cooling system should be carried out by authorised personnel only.



The product's electrical systems should only be installed and serviced by a qualified electrician.

-If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.



Safety valve check:

-Safety valve for boiler/system to be checked regularly.



The product must not be started if it is not filled with water; instructions are in the "Pipe installation" section.



This device can be used by children from the age of eight years and above and by people with reduced physical, sensory or mental ability or lack of experience or knowledge if they have been taught, either with supervision or with the instructions provided, how to use the device safely and understand the risks involved. Children should not play with the device. Cleaning and maintenance should not be carried out by children without supervision.



If these instructions are not followed when installing, operating and maintaining the system, Enertech's commitment under the applicable warranty terms is not binding.

Checklist

The checklist must always be completed by the installation engineer

- If service is needed, you may be required to provide this document.
- Installation must always be carried out according to the installation and maintenance instructions
- Installation must always be carried out in a professional manner

Following installation, the unit must be inspected and functional checks performed as indicated below:

Pipe installation

- ☐ Heat pump filled, positioned and adjusted in the correct manner according to the instructions.
- ☐ The heat pump is positioned so that it can be serviced
- ☐ Capacity of the charge/radiator pump (depending on type of system) for the flow required.
- ☐ Open radiator valves (depending on type of system) and other relevant valves.
- ☐ Tightness test
- ☐ Bleed the system
- ☐ Check proper operation of the requisite safety valves
- ☐ Requisite waste pipes connected to the floor drain (depending on type of system).

Electrical installation

- ☐ Power switch
- ☐ Correct tight wiring
- ☐ Requisite sensors fitted
- ☐ Accessories

Customer information (adapted to the relevant installation)

- ☐ Start-up with customer/installer
- ☐ Menus/controls for selected system
- ☐ Installation and maintenance manual supplied to the customer
- ☐ Check and filling, heating circuit
- ☐ Information on fine adjustments
- ☐ Alarm information
- ☐ Functional test of safety valves fitted
- ☐ Register your Installation Certificate at ctc-heating.com.
- ☐ Information on procedures for fault registration


Date/Customer

Date/Installer

2. Connection alternatives CTC EcoPart 600M

2.1 General

Below are the connection options (controlling products) suitable for CTC EcoPart 600M.



3. Technical data

3.1 Table for CTC EcoPart 612M

Electrical data		EcoPart 612M
Model code		18259
Electrical data		400 V 3N~ 50 Hz
Rated power	kW	5.8
Max. starting current	A	11.9
Compressor max operating current	A	9.7
Max / min fuse rating	A	16 / 13
IP rating (IP)		IP X1

Operating data for heat pump		
Max heat output	kW	11.8
Rated output	@ 0/35 0/45 0/55 kW	6.08 5.68 5.24 @50 rps
Input power	@ 0/35 0/45 0/55 kW	1.27 1.54 1.78 @50 rps
COP	@ 0/35 0/45 0/55 -	4.78 3.68 2.95 @50 rps
Heat output	@ 5/35 5/45 5/55 kW	7.1 6.65 6.36 @50 rps
COP	@ 5/35 5/45 5/55 -	5.62 4.26 3.57 @50 rps
SCOP 0/35 Pdesign cold climate		Pdesign = 11 kW, SCOP = 5.5
SCOP 0/55 Pdesign cold climate		Pdesign = 7 kW, SCOP = 4.3
SCOP 0/35 Pdesign average climate		Pdesign = 10 kW, SCOP = 5.4
SCOP 0/55 Pdesign average climate		Pdesign = 7 kW, SCOP = 4.1

Heating system		
Max temperature heat carrier (TS)	°C	100
Max. operating pressure water (PS)	bar	6.0
Heating carrier system, min flow	l/s	0.28
Heating carrier system, nominal flow	l/s	0.56
Pump performance		Refer to diagram in section "Installation".

Brine system		
Brine volume (V)	l	4.1
Brine system min/max temp (TS)	°C	-5 / +20
Brine system min/max pressure (PS)	bar	0.2 / 3.0
Brine system min flow, $\Delta t = 5$ K	l/s	0.29
Brine system nominal flow, $\Delta t = 3$ K @50 rps	l/s	0.39
Pump performance		Refer to diagram in section "Brine system pump".

Other data		
Refrigerant quantity (R407C, fluorinated greenhouse gas GWP 1774)	kg	2.4
CO ₂ equivalent	ton	4.258
Interrupt value switch HP	MPa (bar)	3.1 (31)
Weight (packaged weight)	kg	170 (188)
Dimensions (depth x width x height)	mm	673 x 596 x 770
Noise level (L_{WA}) @ B0 and W35/55 in compl.w.EN12102	dB(A)	39/41
HP Keymark Cert. No.		012-073

3.2 Table for CTC EcoPart 616M

Electrical data		EcoPart 616M
Model code:		18290
Electrical data		400 V 3N~ 50 Hz
Rated power	kW	7.0
Max. starting current	A	11.7
Compressor max operating current	A	11.1
Max / min fuse rating	A	16 / 13
IP rating (IP)		IP X1

Operating for heat pump			
Max heat output		kW	16
Rated heat output	@ 0/35 0/45 0/55	kW	10.52 9.58 8.90 @50 rps
Input power	@ 0/35 0/45 0/55	kW	2.34 2.80 3.27 @50 rps
COP	@ 0/35 0/45 0/55	-	4.50 3.43 2.72 @50 rps
Heat output	@ 5/35 5/45 5/55	kW	12.26 11.22 10.55 @50 rps
COP	@ 5/35 5/45 5/55	-	5.07 3.87 3.14 @50 rps
SCOP 0/35 Pdesign cold climate			Pdesign = 16 kW, SCOP = 5.5
SCOP 0/55 Pdesign cold climate			Pdesign = 16 kW, SCOP = 4.22
SCOP 0/35 Pdesign average climate			Pdesign = 16 kW, SCOP = 5.2
SCOP 0/55 Pdesign average climate			Pdesign = 16 kW, SCOP = 4.0

Heating system		
Max temperature heat carrier (TS)	°C	100
Max. operating pressure water (PS)	bar	6.0
Heating carrier system, min flow	l/s	0.40
Heating carrier system, nominal flow	l/s	0.81
Pump performance	Refer to diagram in section "Installation".	

Brine system		
Brine volume (V)	l	4.1
Brine system min/max temp (TS)	°C	-5/20
Brine system min/max pressure (PS)	bar	0.2/3.0
Brine system min flow, $\Delta t = 5$ K	l/s	0.29
Brine system nominal flow, $\Delta t = 3$ K @50 rps	l/s	0.39
Pump performance	Refer to diagram in section "Brine system pump".	

Other data		
Refrigerant quantity (R407C, fluorinated greenhouse gas GWP 1774)	kg	2.2
CO ₂ equivalent	ton	3.903
Interrupt value switch HP	MPa (bar)	3.1 (31)
Weight (packaged weight)	kg	172 (190)
Dimensions (depth x width x height)	mm	673 x 596 x 770
Noise level (L_{WA}) @ B0 and W35/55 in compliance with EN12102	dB(A)	36/40
HP Keymark Cert. No.		012-SC0819-18

3.3 Performance data

CTC EcoPart 612M

	Brine temperature in ground circuit	Flow temp.	Output [kW]	Input [kW]	C.O.P. [-]
Frequency 20 Hz	5 °C	35 °C	2,65	0,34	7,76
		45 °C	2,53	0,42	6,01
		55 °C	1,62*	0,55*	2,97*
	0 °C	35 °C	2,27	0,33	6,94
		45 °C	1,97	0,43	4,53
		55 °C	-	-	-
Frequency 50 Hz	5 °C	35 °C	7,08	1,27	5,56
		45 °C	6,54	1,55	4,22
		55 °C	6,09	1,86	3,28
	0 °C	35 °C	5,91	1,30	4,56
		45 °C	5,63	1,53	3,67
		55 °C	5,22	1,90	2,75
Frequency 100 Hz	5 °C	35 °C	13,11	2,34	5,61
		45 °C	12,09	2,89	4,19
		55 °C	12,25	3,35	3,65
	0 °C	35 °C	12,14	2,42	5,01
		45 °C	11,28	2,85	3,96
		55 °C	10,40	3,27	3,19


Note: The values of the operating parameters are measured according to EN 14 511 at the manufacturer's testing laboratory. (Except for values marked *.)

CTC EcoPart 616M


	Brine temperature in ground circuit	Flow temp.	Output [kW]	Input [kW]	C.O.P. [-]
Frequency 20 Hz	5 °C	35 °C	4,90	0,91	5,41
		45 °C	4,64	1,16	3,99
		55 °C	5,17	1,72	3,01
	0 °C	35 °C	4,20	0,90	4,66
		45 °C	3,79	1,18	3,21
		55 °C	4,34	1,70	2,55
Frequency 50 Hz	5 °C	35 °C	12,26	2,42	5,07
		45 °C	11,22	2,90	3,87
		55 °C	10,55	3,36	3,14
	0 °C	35 °C	10,52	2,34	4,50
		45 °C	9,58	2,80	3,43
		55 °C	8,90	3,27	2,72
Frequency 80 Hz	5 °C	35 °C	16,52	4,37	3,78
		45 °C	17,18	5,26	3,26
		55 °C	17,13	5,95	2,88
	0 °C	35 °C	15,60	4,19	3,72
		45 °C	15,44	5,08	3,04
		55 °C	14,77	5,73	2,58

Note: The values of the operating parameters are measured according to EN 14 511 at the manufacturer's testing laboratory.


3.4 Cooling module component location



1. Compressor
2. Evaporator
3. Condenser
4. Drying filter
5. Expansion valve
6. High pressure switch
7. High pressure sensor
8. Low pressure sensor
9. Drain valve cold side/Brine
10. Drain valve warm side/Water
11. Brine pump
12. Charge pump
13. Brine in Ø28 mm (from ground)
14. Brine out Ø28 mm (to ground)
15. Heating water out (flow line) Ø22
16. Heating water in (return line) Ø22
17. Discharge sensor
18. Brine sensor in
19. Brine sensor out
20. Suction gas sensor
21. Return line sensor
22. Flow line sensor
23. AC-chokes (x3)
24. Sensor, AC choke temp




3.5 Dimensions diagram



*The product is delivered with the feet adjusted to a height of 770 mm.
The feet enable height adjustment between 762-797 mm.

3.6 Refrigerant system



3.7 Delivery includes:

- Heat pump CTC EcoPart 600M
- Safety valve 1/2" 3 bar
- Filter ball valve magnet 3/4" *
- Filter ball valve magnet 1" **
- Filler manifold brine G25*/G32**
- Brine vessel*
- 2 x rubber grommets Ø60 (for heating circuit tubes)
- 2 x edging 186 mm (for brine tubes)

* Applies to CTC EcoPart 612M

** Applies to CTC EcoPart 616M

4. Installation

The installation must be carried out in accordance with current standards and regulations. The heat pump must be connected to an expansion vessel in an open or closed system.

Note: If necessary, flush the radiator system before connecting!

Apply all the installation settings based on the description in the chapter on "First start".

4.1 Connection of the heat medium side

Flow and Return Lines must installed for the heat pump; at least Ø22 mm copper tubing for CTC EcoPart 612M and Ø28 mm for CTC EcoPart 616M. Route the pipes so that no other highest point is present where air can collect and obstruct circulation. If however this cannot be done, provide this highest point with an automatic bleeder.

4.1.1 Circulation Pumps (Charging pumps) (G11)

The following circulation pumps are factory-fitted:


CTC EcoPart 616M: UPML - XL GEO 25-125 130 PWM

CTC EcoPart 612M: Yonos Para RS 25/7.5

4.1.2 Pump diagram EcoPart 600M


CTC EcoPart 612M

Yonos Para RS 25/7,5 PWM1 130



CTC EcoPart 616M

UPML - XL GEO 25-125 130 PWM, 1 x 230 V, 50/60 Hz



5. Connecting the ground circuit (brine system)

The brine system, i.e. the ground collector loop, must be assembled and connected by a qualified tradesman in accordance with current regulations and design guidelines.

Care must be taken to ensure that no dirt gets in the collector hoses, which must be washed clean before being connected. The protective caps must remain in place at all times while work is in progress.

The temperature of the coolant system can fall below 0°C. It is therefore important that water-based lubricants, etc. are not used during installation. It is also important that all the components are insulated against condensation to prevent the build-up of ice.


5.1 Connections

The brine system may be connected to the right, left or top of the heat pump, as well as to its rear. Cut away the cover plate on the side where the brine system is to be connected. When the opening has been made through the cover plate, carry out the installation as follows:


1. In order to protect the brine hoses, fasten the protective edging provided around the edge of the opening in the insulation plate. Adjust the length of the protective edging to suit the opening as required.
2. Pass the brine hoses through the opening in the side cover plates and connect them. Ensure that the insulation covers all parts of the brine connection to prevent ice and condensation forming.
3. Then install the collector system according to the section "Brine system schematic diagram".

It is also possible to connect the primary flow on one side of the heat pump and the return on the other. Refer to section "Dimensions diagram" for measurements and dimensions. The pipe dimension between the heat pump and brine loop should be not less than Ø28 mm.


! We recommend that you follow the installation instructions from the local Heat Pump Association.



Possible take-offs, Brine hoses



Edging strips (x2), supplied




5.2 Brine system schematic diagram

The diagram shows the main connection for the brine system. The filling equipment is represented by the parts displayed with dashes.

Note: Collector hoses must have a bleeding facility as air pockets can occur.

Always check the filter (99) when filling and bleeding the brine system.

! The mixing vessel and filling pump must be of an adequate dimension.



- 96 Level/expansion vessel
- 97 Filling kit
- 98 Shut-off valve
- 99 Filter
- 100 External filling pump

- 101 Mixing vessel
- 102 Brine pump
- 103 Evaporator
- 104 Safety valve 3 bar

5.2.1 Valves

To facilitate servicing of the cooling unit, shut-off valves must be fitted to both the incoming and outgoing connections. Mount the valves (98d and 104) with the bifurcation so that you can later fill and bleed the collector circuit.

5.2.2 Insulation against condensation

All pipes in the brine system must be insulated against condensation to prevent the possibility of severe build-up of ice and condensation dripping.

5.2.3 Filling and venting

The collector circuit must not contain any air. Even the smallest amount of residual air can jeopardise the heat pump's operation.

Mix water and antifreeze solution in an open vessel. Connect hoses to the shut-off valves (98a and 98b) as shown in the figure.

Note: The hoses must have a minimum diameter of 3/4". Connect a powerful external pump (100) for refilling and bleeding. Open the valves (98a and 98b) so that the brine passes through the mixing container (101). Also make sure that the valve (98d) is open.

To start the brine pump, refer to the manual of the controlling product.

Allow the brine to circulate in the system for a long period of time until it is completely free of air. There could still be air in the system, even though no air accompanies the liquid out.

Bleed the level vessel (96) by loosening the plug on the top of the level vessel.

Now close the valve (98a) while the filling pump continues to run. The filling pump (100) now pressurises the system. Also close the valve (98b) and shut off the filling pump.

If the level in the level vessel is too low, close the valves (98c) and (98d). Unscrew the plug and fill the vessel to around 2/3 full. Screw the plug back in and open the valves (98c) and (98d).

5.2.4 Pressure/level switch

In some cases, extra protection is required due to local requirements or provisions. For example, the requirement in some areas is for the system to be installed within a water catchment area. If there is a leak, the compressor and brine pump stop and the Flow/level switch alarm appears on the controlling product's display. For connection, see the manual for the controlling product.

5.2.5 Post-installation check on brine system


After a few days, you must check the fluid level in the vessel. Fill if necessary and close the valve (98c) when filling.


5.2.6 Level vessel/Expansion vessel (CTC EcoPart 612M)


The level vessel (96) should be fitted to the incoming line from the borehole or ground, at the system's highest point. This applies to CTC EcoPart 612M (CTC EcoPart 616M has no level vessel). Bear in mind that the tank can produce condensate on its exterior. Mount the safety valve (104) according to the principle sketch and install the appropriate stopper at the top of the vessel. If the receptacle cannot be mounted at the highest point, a closed expansion vessel shall be fitted.

5.2.7 Filling kit with dirt filter

Arrows on the valve housing indicate the flow direction. Close the valve (98c) when cleaning the filter. Unscrew the filter cap and flush the filter clean. When refitting, the pin under the filter holder should be fed into the designated hole in the filter housing. Top up with a little brine, if necessary, before fitting the cap. The filter should be checked and cleaned after a short period of operation.

 Check the dirt filter after bleeding has been completed.

 The fluid must be thoroughly mixed before the heat pump is started.

 Check the dirt filter in the brine system after a few days' operation.

5.2.8 Brine

The brine circulates in a closed system. The fluid consists of water and antifreeze solution. CONVECTHEAT R is recommended for use in the brine circuit.

5.2.9 Air pockets

To avoid air pockets, make sure that the collector hoses constantly rise towards the heat pump. If this is not possible, it must be possible to bleed the system at the high points. The filling pump usually copes with smaller local height discrepancies.

5.2.10 Checking brine difference


When the heat pump is running, regularly check that the temperature difference between incoming and outgoing brine temperatures is not too large. If there is a large difference, one of the causes may be due to air in the system or a blocked filter. If this is the case, the heat pump triggers the alarm.

The alarm factory setting is 7°C, but 9°C is permitted for the first 72 hours while the compressor is running, as microbubbles in the system can reduce brine flow.

5.3 Refrigerant pump (G20)

For CTC EcoPart 612M and 616M, a circulation pump is used:

UPMXL - GEO 25-125 180 PWM, 1 x 230 V, 50/60 Hz.



6. Electrical installation

Installation and heat pump connection must be carried out by an authorised electrician. All wiring must be installed according to applicable provisions. Before the front panel is opened or other live components are made accessible, the power supply to the heat pump must be fully disconnected.



6.1 Electrical installation 400 V 3N~

CTC EcoPart 600M must be connected to 400 V 3N~ 50 Hz with protective earth.

The 2 meter long power cable is fully wired in the heat pump and is routed via the terminal box X1 on the left rear. Disconnecting the power cable will render the heat pump warranty null and void.



6.1.1 Omnipolar safety switch

The installation should be preceded by an all-pole safety switch according to overvoltage category III, which ensures disconnection from all electric power sources.

The EcoPart 600M should be equipped with a faulty residual current switch with delayed deactivation.

6.1.2 Alarm output


The CTC EcoPart 600M is fitted with a potential-free alarm output which is activated if any alarm is active in the heat pump. This output may be connected to a maximum load of 1 A 250 V AC. An external fuse should also be used. A cable approved for 230 V AC must be used for connecting this output, irrespective of the load that is connected. For connection, see the chapter entitled "Wiring diagram".



Alarm output, detailed view from electrical diagram


7. Communication connection

The 2 metre long communication cable is pre-wired in the heat pump and is routed via the connector box (X1) to the right rear of the heat pump for connection to the controlling product.




7.1 Option 1 - Connection of one heat pump

The communication cable of the heat pump (LiYCY (TP)) is connected directly to the respective controlling product. When installing only one heat pump, make sure that DIP switch 2 is in the ON position (pre-set factory value).



Connection of communication with IR14 CTC controller




! When connected in series, the last heat pump must be set to the terminated position. Read more under the chapter 7.2 Series connection of heat pumps.

Connection of communication with RegulusBOX CTC, Regulus HBOX CTC and Regulus HBOX K CTC indoor units

CTC EcoPart HEAT PUMP

IR 14 CTC controller




7.2 Option 2 – Series connection of heat pumps

When connected in series, the shielding of the communication cable on the last heat pump must be connected to earth (see shielded communication) and the heat pump itself must be terminated (see terminated position).


! When connecting heat pumps in a cascade, DIP switch 2 must be set to OFF for all pumps except the last one; for the last heat pump in the series DIP switch 2 must be set to ON.

Heat pumps in series connection

The last heat pump connected in series



Shield connection diagram



Addressing heat pump cascades


EP600 heat pumps have a factory-set address as 1. For further heat pumps, the address needs to be changed. Addressing is done in the IR14 controller, in the HEAT PUMP / MODBUS COMMUNICATION menu. The addressing procedure is as follows: All heat pumps must be disconnected from the power supply (switched off at the circuit breaker), turn on the power supply for the heat pump you want to address. The heat pump will start communicating with the IR controller as HP1 (factory-set address 1), go to the MODBUS COMMUNICATION menu and change the HP address to be set to number 2. Click the set address button. Check whether heat pump 2 is communicating and whether you can see the values on the sensors in the HP 2 menu. Address the other heat pumps using the same procedure.


From the communication point of view, the order of the heat pumps does not matter. However, it is important that each heat pump has a unique address in the range from 1 to 10.




7.3 Wiring diagram

7.3.1 Cooling module (A3)






7.3.2 Cooling module (A4)



7.3.3 Connection box



7.4 Parts list

A2	Relay/main card (CTC EcoLogic / EcoZenith i555 Pro)	
A5	HP control card	
A10	Soft-start card with motor protection and contactor function	
B21	Discharge sensor	Type 3/ NTC
B22	Suction gas sensor	Type 1/ NTC
B23	Brine sensor in	Type 1/ NTC
B24	Brine sensor out	Type 1/ NTC
B27	Heat pump in	Type 2/ NTC
B28	Heat pump out	Type 2/ NTC
B40	Sensor, AC choke temp	NTC 015
B100	High pressure sensor	
B101	Low pressure sensor	
F10	Max thermostat	
F20	High pressure switch	
G11	Heating circuit pump	
G20	Brine pump	
G21	Groundwater pump, signal 230 V, optional	
K1	Contactor	
L1	AC coils (harmonic filter)	
M1	Compressor	
X1	Connection box, terminal	
Y10	Expansion valve	

7.5 Resistances for sensors

Temperature °C	Sensor Type 1 NTC Resistance kΩ	Temperature °C	Sensor Type 2 NTC Resistance kΩ	Temperature °C	Sensor Type 3 NTC Resistance kΩ	Temperature °C	NTC 015 Resistance kΩ
100	0.22	100	0.67	130	5.37	110	0.76
95	0.25	95	0.78	125	6.18	105	0.86
90	0.28	90	0.908	120	7.13	100	0.97
85	0.32	85	1.06	115	8.26	95	1.11
80	0.37	80	1.25	110	9.59	90	1.27
75	0.42	75	1.47	105	11.17	80	1.67
70	0.49	70	1.74	100	13.06	75	1.92
65	0.57	65	2.07	95	15.33	70	2.23
60	0.7	60	2.5	90	18.1	65	2.59
55	0.8	55	3.0	85	21.4	60	3.02
50	0.9	50	3.6	80	25.4	55	3.54
45	1.1	45	4.4	75	30.3	50	4.16
40	1.3	40	5.3	70	36.3	45	4.91
35	1.5	35	6.5	65	43.6	40	5.83
30	1.8	30	8.1	60	52.8	35	6.9
25	2.2	25	10	55	64.1	30	8.3
20	2.6	20	12.5	50	78.3	25	10.0
15	3.2	15	15.8	45	96.1	20	12.1
10	4	10	20	40	119	15	14.7
5	5	5	26	35	147	10	18
0	6	0	33	30	184	5	22
-5	7	-5	43	25	232	0	27
-10	9	-10	56	20	293	-5	34
-15	12	-15	74	15	373		
-20	15	-20	99	10	479		
-25	19	-25	134	5	619		
-30	25	-30	183				

8. First start

1. Check that the heating boiler and system are full of water and have been bled.
2. Check that all connections are tight.
3. Check that sensors and the radiator pump are connected to the power source.
4. Energise the heat pump by switching on the safety switch (the main switch).

Once the system has heated up, check that all connections are tight, the various systems have been bled, heat is coming out into the system and DHW is coming out at the tap locations.

9. Operation and Maintenance

When the installer has installed your new heat pump, you should check along with the installer that the system is in perfect operating condition. Let the installer show you where the power switches, controls and fuses are so that you know how the system works and how it should be maintained. Bleed the radiators (depending on type of system) after around three days of operation and top up with water to the required heating water pressure if required.

9.1 Periodic maintenance

After three weeks' operation and then every three months during the first year. Then once a year:

- Check that the installation is free of leaks.
- Check that the product and system are free of air, bleed if needed – see the chapter “Connection of brine system”.
- Check that the brine system is still pressurised and that the fluid level in the brine vessel is adequate/correct.
- The products do not require annual inspection for refrigerant leakage.

9.2 Operation stop

The heat pump is shut down using the operating switch. If there is a risk of the water freezing, drain off all the water from the CTC EcoPart 600M.

10. Troubleshooting/Appropriate measures

The CTC EcoPart 600M is designed to provide reliable operation and high levels of comfort, as well as a long service life.

If a fault occurs, you should always contact the installer who installed your unit. If the installer believes the malfunction is due to a materials or design fault, then they will contact Regulus to check and rectify the issue. Always provide the heat pump's serial number.

10.1 Air problems

If you hear a rasping sound from the heat pump, check that it is properly bled. Top up with water where required, so that the correct pressure is achieved. If this noise recurs, call a technician to check the cause.

10.2 Alarm

Any alarms and information texts from the CTC EcoPart 600M are displayed in the controlling product; refer to that product's manual.

Removing the cooling module



- Any work done on the product's cooling system should be done by authorised personnel only.
- Close the safety switch before doing any work on the product.



1. Disconnect the cooling module's power cable connector and hoses.



2. Attach the two carrying handles to the bottom of the cooling module.



3. Unscrew the cooling module's screws.


4. Fold out the front cable harness and loosen the flat pin on the red EMC cable.



5. Pull the cooling module by first lifting the front edge slightly with the carrying handles.



6. Lift the cooling module using the carrying handles and shoulder straps.



7. Lift the cooling module into the product using the carrying handles and shoulder straps. Remove the carrying handles and reconnect the power cable, hoses and screws.

8. Before the cooling module is tightened into position, ensure the EMC cable is affixed.



