

Filter installation into Sentinel Kinetic Advance S, SX HRV Unit

1. Open the filter drawers by pressing the finger plate upwards and sliding the drawer out.




2. Remove the filters from the drawers and replace with new ones.

set of **G3 filters**



Set of **F5 pollen filters** (shall be shifted into the openings)



3. Close the filter drawers, ensuring the latches have clicked back into the locked position.
4. After maintenance of the filters, the filter timer can be reset by going to Settings/Performance, Clean/Replace filter, see pics.

How to reset the timer in the digital menu

